LBT-N355

MANUAL DE SERVIÇO

BRAZILIAN MODEL

RM-SD50
Controle Remoto

Especificações técnicas

SEÇÃO DE CD	Tipo de Mecanismo	CDM37-5BD19
	Tipo de Base	BU-5BD19
	Tipo de Unidade Ótica	KSS-213BA/S-N
SEÇÃO DE TAPE DECK	Modelo que usa mecanismo similar	LBT-N555
	Tipo de Mecanismo	TCM-220WR2E

Sintonizador
Sintonizador superheteródino de FM/AM, FM estéreo
Sintonizador de FM (freqüência modulada)
Faixa de sintonia
87,5 – 108,0 MHz (intervalo de 50 kHz)
Antena Cabo de antena de FM
Terminais de antena
75 Ω não balanceado
Sintonizador de AM (ondas médias)
Faixa de sintonia
530 – 1.710 kHz (com intervalo de sintonização ajustado a 10 kHz).
Antena Antena loop de AM
Terminais para antena externa
Freqüência intermediária
450 kHz

Reprodutor de CDs
Sistema Sistema de áudio digital de discos compactos
Laser Laser semiconductor (λ = 780 nm) Duração da emissão: contínua
Saída do laser Máx. 44,6 µW
Resposta de freqüência
2Hz – 20KHz (± 0,5 dB)
Comprimento da onda
780 – 790 nm

Reprodutor de fitas
Sistema de gravação
4 pistas e 2 canais, estéreo
Resposta de freqüência
40 – 13.000 Hz (±3 dB), com fita cassete Sony tipo I
40 – 14.000 Hz (±3 dB), com fita cassete Sony tipo II
Wow flutter
0,1% WRMS (NAB)

SISTEMA INTEGRADO DE SOM

SONY

5-8. SCHEMATIC DIAGRAM — CD PANEL SECTION —



09

NOTE

- All capacitors are in μF unless otherwise noted. pF: μμF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4W or less unless otherwise specified.
- [ ] :panel designation.

1 2 3 4 5 6 7 8 9 10 11 12

A B C D E

NOTE

- All capacitors are in μF unless otherwise noted. pF: μμF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4W or less unless otherwise specified.
- B+ :B+ Line.
- Voltages and waveforms are dc with respect to ground under no-signal conditions.
  no mark: STOP
- Voltages are taken with a VOM (Input impedance 10MΩ). Voltage variations may be noted due to normal production tolerances.



5-20. SCHEMATIC DIAGRAM — CD MOTOR SECTION —



5-18. SCHEMATIC DIAGRAM — CD PANEL SECTION —

- Semiconductor Location

Ref. No.	Location
IC601	H-3
IC602	G-4
IC611	H-9
Q621	H-6
Q622	H-6
Q623	H-5
Q651	F-9
Q1001	B-2
Q1002	B-6



NOTE

- All capacitors are in μF unless otherwise noted. pF: μμF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4W or less unless otherwise specified.
- [ ] : panel designation.
- JW : Jumper Wire

RING BOARD — DECK SECTION —
8 for Circuit Boards Location.

Note:

- ○—— : parts extracted from the component side.
- : Pattern from the side which enable seeing.

2	3	4	5	6	7	8	9




A
TCB BOARD
CN1
(Page 44,48,51)
COM-DATA
COM-DIN
ST-CE
ST+10V
TUNED
STEREO
ST-L
A.GND
ST-R
MUTE
A+7V (UNSW)
A-7V (UNSW)
B
DECK
SECTION
(Page 63)
REC-L
REC-R
DGND
-7.5V
AGND
+7.5V
+5V (UNSWITCHED)
-7.5V (M)
+5V (M)
PB-L
PB-R
TC CONTROL BUS LINE
TC-BUS
C
BG BOARD
CN102
(Page 38)
FOCUS-SW
SCOR
SQ-DATA
SQ-CLK
SENS
DF-LAT
CD-DATA
X-LAT
CD-CLK
X-RST
D+5V (SW)
D-OUT
D-GND
A+5V (SW)
R-CH
A-GND
L-CH
M-GND
+7V (UNSW)
CN201
E
CD MOTOR BOARD
CN201
(Page 40)
D.GND
TRAY.SENS
5V
M.GND
TBL-L
TBL-R
7V
LED
UP.SW
IC701
TMP87CS64YF
MASTER CONTROL
4Vp-p
32.768kHz
2.8Vp-p
10MHz
X701
X702
32kHz
RESET SWITCH
ST-RCH
TCPB-LCH
CB-LCH
CB-RCH
TCPB-RCH
B+
B-

[MAIN BOARD (1/2)]

*JW801, JW809, JW851, JW859




C1237HA
IC901
EQ/VOLUME
5BAND GEQ
5BAND GEQ
IC902
AMP
Q902
FEED BACK
SWITCH
Q952
FEED BACK
SWITCH
IC1202
PROTECTOR
STANDBY SW
L STANDBY
H ACT
POWER OFF MUTE
MUTE
SWITCH
MUTE
SWITCH
IC802
MC14052BCP
LC901
M62427FP
POWER AM
REC-L
REC-R
PS-LCH
PS-RCH
ST-RCH
CD-RCH
+7V
-7V
ST A.GND
TC H-7.5V
TC H+5V
H.GND
A.GND
TC 0+5V
ST +10V
R740
3.3k
R741
10k


IC701
TMP87CS64YF
IC701
MASTER CONTROL
IC1003
+7V REG
IC1004
-7V REG
IC1002
+7V REG
IC1001
+5V REG
IC702
RESET
CD MOTOR
U-COM +5V
Q1001, 1002
CD POWER
ON/OFF
SWITCH
4Vp-p
32.768kHz
2.8Vp-p
10MHz
CD 5V
CD +7V
CN702
21p
PANEL BOARD
CN501



NOTE

- All capacitors are in μF unless otherwise noted. pF: μμF
  50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4W or less unless otherwise specified.
- △ : internal component.
- ⏦ : nonflammable resistor.
- ⏦ : fusible resistor.
- ▭ : panel designation.

Note:	Note:
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- B+ : B+ Line.
- B- : B- Line.
- Voltages and waveforms are dc with respect to ground under no-signal (detuned) conditions.
  no mark: FM
  ( ): CD PLAY
- Voltages are taken with a VOM (Input impedance 10MΩ). Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with a oscilloscope. Voltage variations may be noted due to normal production tolerances.

10


L STANDBY
H ACT
Q1206
DATA4H
POWER OFF MUTE
5.0
R1250
10k
H OFF
Q1207, 1208
RELAY
SWITCHING
*Q1207, Q1208
2SA1175
*R1222, R1223, R1272, R1273
220 1/2W
TH1202
SURROUND
SPEAKER
26.5V-37.5V
D1250
B59RA20F01
C1230
50V
C1235
50V
C1271
0.22
/100
C1270
0.22
/100
R1273
R1223
R1272
R1222
B+
B-
IC1003
+7V REG
IC1004
-7V REG
IC1001
+5V REG
Q1003
+10V REG
Q1006
-25V REG
*:C1230, C1235
3300 50V
*D1309, D1310
IN4148M
TA AC OFF
D1309
D1310
R1303
4.7k
R1304
4.7k
CN1001
CN1604
EH-L
AC12V
A-GND
AC12V
AC16V
AC-POWER
P-GND
AC-POWER
VF1
VF2
【TRANS BOARD】
R1603
0.15
R1602
0.15
R1601
0.68
C1600
0.1
C1601
0.1
F1604
T1.6A 250V
F1603
T4A
250V
T4A 250V
VS1601
VOLTAGE
SELECTOR
220-240V
110-120V
CN1601
2P
CNP1601
AC IN
T1601
POWER
TRANSFORMER
(CHASSIS)
FL -25V
30mA
-32V
10V/mA
5T +10V
*Signal path,
:FM
:VIDEO/AUDIO
:PB
:CD


21
22
23
24
25
26
27
28
29
30
31
32
【PANEL BOARD】(2/2)
IC808 (1/2)
MIC AMP
IC808 (2/2)
MIC/ECHO MIX AMP
R875 220
+7V
-7V
CN801
A+7.5V
MIC-OUT
A-7.5V
A-GND
【CD LED BOARD】
CN506
CN516
R3151 390
(CD)
CN501
21P
VF
VF
VFOP (-25V)
D+5.0V
D.GND
RESET
RDY.MG
REQ.GH
CLK.MG
DATA.GH
DATA.MG
SPA.SIG
HP-L
JACK-SW
HP-R
GND
A+7.5V
A-7.5V
POW-ON
MIC-OUT
A-GND
(Page 58)
MAIN BOARD
CN702
D
【MIC BOARD】 IC901
MIC AMP
IC901
MIC
MIC LEVEL
【HP BOARD】
LOW



NOTE

- All capacitors are in μF unless otherwise noted. pF: μμF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4W or less unless otherwise specified.
- △ : internal component.
- ▭ : panel designation.
- B+ : B+ Line.
- B− : B− Line.
- Voltages and waveforms are dc with respect to ground under no-signal (detuned) conditions.
  no mark: FM
- Voltages are taken with a VOM (Input impedance 10MΩ). Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with a oscilloscope.
  Voltage variations may be noted due to normal production tolerances.


FL501
FLUORESCENT INDICATOR TUBE
IC502
REMOTE CONTROL RECEIVER
IC504
INVERTER
IC501
DISPLAY CONTROL
POW-ON
CN501
CN506
CN514
LOW


TUNING MODE
KARAOKE PON/MPX
EFFECT
CLOCK SET
SLEEP
SYSTEM POWER
FILE 4
FILE 3
FILE 2
FILE 1
EQ MEMORY
FUNCTION
TIMER SET
DAILY 1
DAILY 2
REC
DISPLAY /DEMO
ENTER /NEXT
SURROUND
TUNER MEMORY
STEREO/MONO
IC503
MC14053BCP
MODE SELECT
IC504
INVERTER
IC504 (3/5) SN74HC04AN
IC504 (4/5) SN74HC04AN
IC504 (5/5) SN74HC04AN
LED SWITCH
TUNER/BAND
Q611, 612 SWITCH
ENTER/NEXT
FILE
CLASSIC STUDIO
POPS DANCE
EFFECT
SELECT 5
MORE 5
SALSA CHURCH
JAZZ STUDIUM
ROCK GAME
Q621-625, 629-634 LED SWITCH
A+7.5V
MIC-OUT
A-7.5V
A-GND
HP-L
HP-R
RY-OFF
JACK SW
LOW
HIGH
NOT-TU
NOT-CD
NOT-TC
CD
B+
GND
D+5V
A+7V

5-21. DIAGRAMA ESQUEMÁTICO - SEÇÃO PAINEL DE CD -

• See page 19 for IC Pin Function. (IC501)



【TC CONTROL BOARD】

• IC Block Diagram

IC806 M65843FP



08

CD (R) BOARD CN514 (Page 67) G

CD (L) BOARD CN515 (Page 67) H

FILE 5 FILE SELECT FILE 4 FILE 3

TUNER/BAND DBFB SURROUND

TUNING TUNER MEMORY STEREO/MONO

5-16. SCHEMATIC DIAGRAM — DECK SECTION — • See page 54 for Printed wiring Board. (MAIN BOARD)




【MAIN BOARD (2/2)】
(DECK SECTION)
【MOTOR BOARD】
IC401
DECK PROCESS
IC402
TRIGGER MOTOR DRIVER
CN651 6P
CN401 21P
CN402 11P
CN1001
M1 CAPSTAN MOTOR
M2 TRIGGER MOTOR
REC LEVEL R
REC LEVEL L
CAPM-
CAPM H/L
CAPM+
TRGM+
TRGM-
7.5V
APB LCH
APB RCH
AGND
BPB LCH
BPB RCH
-7.5V
RELAY
BIAS
-VBIAS
+VBIAS
REC RCH
REC LCH
BIAS-HX
VREF-HX
HEAD-EARTH
AHALF
APLAY
A120/70
ASHUT
BHALF
+5V
DGND
BSHUT
BMETAL
BPLAY
B120/70
A HALF
A PLAY
A120/70
A SHUT
B HALF
+5V
DGND
B SHUT
B METAL
B PLAY
B120/70
Q403, 406, 407
CAPSTAN MOTOR
CONTROL

14



NOTE

- All capacitors are in μF unless otherw 50WV or less are not indicated except and tantalums.
- All resistors are in Ω and 1/4W or les specified.
- ⚠ :fusible resistor.

Note: The components identified by mark ⚠ line with mark ⚠ are critical fo Replace only with part number spec

- B+ :B+ Line.
- B− :B− Line.
- ▭ :adjustment for repair.
- Voltages and waveforms are dc with resp under no-signal conditions.
  no mark: PLAY
  ( ): REC
- Voltages are taken with a VOM (Input imp Voltage variations may be noted due to tion tolerances.
- Abbreviation
  G :German model.
  IT :Italian model.
  EE :East European model.
  MX :Mexican model.
  AUS: Australian model.
  AR :Argentine model.
- Signal path.
  ⩾ :PB (DECK A)
  ▷ :PB (DECK B)
  ▷» :REC (DECK B)

IC401 HA12195T



IC401 HA12196T



5-16. DIAGRAMA ESQUEMÁTICO - SEÇÃO DECK -See page 54 for Printed wiring Board. (MAIN BOARD)




— B DECK —
HRPE101
RECORD/PLAYBACK/
ERASE HEAD
L-CH
R-CH
IC601
μPC4570C-1
PB AMP
PB LEVEL L
PB LEVEL R
IC602
REC/PB
SWITCH
μPC1330HA
SW.R1
GND
SW.P1
CONT
GND
VCC
SW.P2
GND
SW.R2
REC BIAS
R
REC BIAS
L
Q621, 622
BIAS
OSC
Q623
BIAS ON/OFF
SWITCH
2SC2001
2SB1387
CN602
CN601
CAPH-
CAPH+
TRGH+
TRGH-
7.5V
APB LCH
APB RCH
AGND
BPB LCH
BPB RCH
-7.5V
RELAY
BIAS
-V BIAS
+V BIAS
REC RCH
REC LCH
BIAS HX
VREF HX
HEADEAR
【LEAF SWITCH BOARD】
Q1001
NJL5165K-A
Q1002
NJL5165K-A
S1001, 1002
REEL
DETECT
S1003
A HALF
S1004
A CrO2
S1005
REC A
S1006
B HALF
S1009
REC B
S1008
B CrO2
S1001
A PLAY
S1002
B PLAY
CN1001
A HALF
A PLAY
A120/70
A SHUT
B HALF
+5V
GGND
B SHUT
B METAL
B PLAY
B120/70

5-8. DIAGRAMA ESQUEMÁTICO - SEÇÃO SINTONIZADOR -



3



• Semiconductor Location

Ref. No.	Location
D1	F-2
D2	E-3
IC1	F-3
IC2	C-3
Q1	E-2
Q2	E-3
Q3	D-2
Q4	D-2
Q5	D-3

NOTE

- All capacitors are in μF unless otherwise noted. pF: μμF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4W or less unless otherwise specified.
- △ :internal component.
- ▭ :panel designation.
- B+ :B+ Line.
- ▭ :adjustment for repair.
- Voltages and waveforms are dc with respect to ground under no-signal (detuned) conditions.
  no mark: FM
  ( ): AM
  * :can not be measured.
- Voltages are taken with a VOM (Input impedance 10MΩ)
  Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with a oscilloscope
  Voltage variations may be noted due to normal production tolerances.

• Signal path.
⇨ :FM
➡ :AM

Note:
- o—— : parts extracted from the component side.
- △ : internal component.
- ▨ : Pattern from the side which enable seeing.

5-5. DIAGRAMA ESQUEMÁTICO - SEÇÃO CD -

• See page 79 for IC Block Diagrams. (IC101 — 104)





NOTE

- All capacitors are in μF unless otherwise noted. pF: μμF
  50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and 1/4W or less unless otherwise specified.

Note:	Note:
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- Signal path.
  ⇨ : CD
- B+ : B+ Line.
- ▭ : adjustment for repair.
- Voltages and waveforms are dc with respect to ground under no-signal conditions.
  no mark: STOP
  ( ): PLAY
- Voltages are taken with a VOM (Input impedance 10MΩ)
  Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with a oscilloscope.
  Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.

2